

Ply Lag



Description:

OCM, Inc's Ply Lags are used to fasten wales or strongbacks. They can also be used internally to fix coil ties (etc.) to the form.

Features:

- Made with high strength steel.
- Available in 9 different lengths.

Additional Notes: SWL provides a safety factor of approximately 2 to 1.

Item Number	Safe Working Load (lbs)	D Size (in)	L Length (in)	Overall Length (in)
PL50-14.75	3,000	1/2"	11"	14-3/4"
PL50-5.75	3,000	1/2"	3"	5-3/4"
PL50-6.25	3,000	1/2"	3-1/2"	6-1/4"
PL50-6.75	3,000	1/2"	4"	6-3/4"
PL50-7.25	3,000	1/2"	4-1/2"	7-1/4"
PL50-8.75	3,000	1/2"	6"	8-3/4"
PL50-9.75	3,000	1/2"	7"	9-3/4"
PL50-10.75	3,000	1/2"	8"	10-3/4"
PL50-12.75	3,000	1/2"	10"	12-3/4"